

HF710 Portable Bluetooth headest USER GUIDE



Familiar with your Bluetooth speaker

Thank you for selecting Bluetooth headset HF710

HF710 stereo Bluetooth headset make you have more interaction & entertainment in your own music space, and synchronize your work in hand at the same time after paired with the compatible mobile.

HF710 Bluetooth headset is complaint with Bluetooth Version 4.0 +EDR (Enhanced Data Rate) and is compatible with latest mobile phones supporting Bluetooth headset or handsfree profiles.

1.Charging Socket

5. 3.5mm Audio Cable Socket

2 .Previous Track
3 Next Track

Multifunction Button (MFB)
 NEC Induction Position

4. Volume Down -

8 Volume Up +





Overall Schematic

Use Instructions

Getting Started HF 710

Prior to using your Stereo Bluetooth headset,please follow the steps below:

- 1.Ensure your Bluetooth headset is fully charged.
- Pair your charged Bluetooth headset with a Bluetooth-enable mobile phone, before use for the first time, it is suggested that you fully recharge the battery first.

Charging Your Headset

The indicator will turn red while charging it turns blue after 2-3 hours when it is fully charged. (Note: if blue indicator flashes quickly and could not enter pairing, it tells the battery need to be charged)

Turning on/off the headset

Press and hold the MFB for 3 seconds until "Power On" & "Power off" Voice prompt.

About pairing function, please refer to "Pairing Your Headset".

Turn on/off by NFC

(Note: Version of NFC function on mobile phone must be 4.1 or above) In off status, turn on your mobile Bluetooth&NFC function and place it 1 cm closing to """ APEC", the headset boots with "Power On" prompt and will your mobile phone prompts whether to pair or not, press "OK" and it will connect automatically with "Connected" prompt. (Reneat to turn it off)

Pairing Your Headset

The headset works with Bluetooth-enable phones, prior to using and pairing your headset for the first time ,please check if your mobile phone is Bluetooth-enable or not.

The headset pairing procedure may vary depending on the setting of your mobile phone. For further information, please contact the manufacture or distributor of your mobile phone.

Subsequent Pairing

- 1. Get the headset and the mobile phone close to each other.
- 2. Ensure the headset is turned off.
- Press and hold the MFB for 5 seconds until voice prompt "Bluetooth Pairing" and the blue&red indicator flash alternately, the headset enters pairing.
- 4. Activate the Bluetooth function on your mobile phone.
- 5. Search for Bluetooth devices select "HF 710" and it will connect automatically with "Connected" announcement.
- 6. If password is needed please enter " 0000 ".
- 7. Now you can use your Bluetooth headset to listen to the music and make a call.
- 8. Some mobile phones ,when they are re-started ,the headset will be connected with the mobile phone automatically.

Connect&Standby

Turn on the headset and it will connect the last connected mobile phone automatically, if successfully connected, it will enter standby mode or if it fail, it will shut down automatically after 5minutes.

Multipoint Connection

Method 1

After mobile phone is paired successfully with the headset, turn off the headset and re-enter pairing status, then use your other mobile phone to pair with the headset. After the second mobile phone is paired with the headset successfully, search for the paired record on your first mobile

phone and connect it.

Method 2

After mobile phone is paired successfully with the headset, turn off the headset and re-enter pairing status, then use your other mobile phone to pair with the headset. After the second mobile phone is paired with the headset successfully, turn off the headset again. Then when you turn on you headset and it will connect the last connected 2 mobile phones automatically.

Wearing Your Headset

Please follow the Left/Right wearing note inside the headband, or ensure the button position on your right when wearing the HF 710.

Using Your Headset

Answering a Call

When call comes, you can hear the ring tone on headset, press the MFB once to accept the call or answer the call via your mobile phone in normal way.

Call mute

During the call, press and hold the volume key " - " to make the call mute. (Repeat to delete mute)

Transferring a Call

During the call, press&hold the volume key "+" for 2 seconds after "DU" tone is heard to transfer the call from your headset to your mobile phone.

Rejecting a Call

Double click the "MFB" to reject the incoming call.

End the Call

During the call, press the " $\rm MFB$ " once to end the call or hang up by your mobile phone.

Last call redialing

In standby mode, double click the " \mbox{MFB} " to redial the last call you made.

Voice Dialing

In standby mode, press and hold the volume keys " + " & " - " simultaneously and speak out the voice tag of the name recorded to the number you want to dial.

Notice: prior to "HF 710" voice dialing, please make sure your mobile phone stored the voice tag: name. Ensure voice dialing function has been successfully activated on your mobile phone. Regarding how to record the voice tag, please refer to your devices user guide.

Turn Up the Volume

(During calling/Bluetooth music) Click the volume "+" once, the volume will be up. Each click per level, until to the MAX and you will hear "DU" alarm.

Warm Prompt: Adjust the volume properly to avoid any damages to your ears.

Turn Down the Volume

(During calling/Bluetooth music) Press the volume "-" once, the volume will be down. Each click per level, until Min and you will hear "DU" alarm.

Play/Pause

When the Bluetooth headset was connected with stereo mobile phone, press "MFB" once to play music and press it once again to pause music .(Attention:your mobile phone must support A2DP profile.)

Previous Track

Connected with stereo mobile phone and playing music, press the "Previous Track" button to select the previous track.

Next Track

Connected with stereo mobile phone and playing music, press the "Next Track" key to select next track.

3.5 audio function works in on or off status, music will be cut down to the MIN volume in order not to affect the talk, the headset will return to music after call end.

Troubleshooting

If you are unable to connect your speaker with the mobile phone, please try the following steps:

- Ensure your speaker is turned on and is fully charged.
- Ensure the speaker has been paired with your mobile phone.
- Ensure your mobile phone's Bluetooth feature is activated. Please refer to your mobile phone user guide for specific instruction.
- Ensure the speaker is within 10 meters range of your mobile phone and there are no obstructions, such as walls or other electronic devices.

If the above steps do not solve your problem, please recharge the speaker and remove your mobile phone battery for a short time.

Safely Information

Check local laws regarding the use of mobile phones and speakers while driving. If you use the speaker while driving, ensure your attention and

focus remains on the road and you drive in a responsible and safe manner.

Never allow children playing with the speaker small parts may be a choking hazard. Observe all signs that require an electrical device or RF radio product to be switched off in designated areas. (These could include hospitals, blasting areas, and potentially explosive environments.)Turn off your speaker prior to boarding an aircraft. Do not use your speaker in an aircraft. Never mount or store your speaker over any air bag development area as serious injury may result when the air bag deploys. Do not open or mutilate the built-in battery. Dispose of batteries according to local regulations. Do not dispose as household waste.

Maintenance

- Turn your speaker off before placing it in your pocket or bag to avoid the MBF button is accidentally touched.
- Do not expose the speaker to liquid or moisture environment as it is not waterproof.
- Do not use abrasive cleaning solvents to clean the speaker.
- •Do not expose the speaker to extreme temperature conditions. The best store temperature range is from -10 to +60, otherwise the life of the speaker will be influenced.
- Do not dispose of the speaker in a fire as it this may result in an explosion.
- Do not bring your speaker into contact with sharp objects as this will cause scratched and damage.
- Do not attempt to disassemble the speaker as it dose not contain serviceable components.

If you do not use the speaker for long periods, be sure to store it in a dry place, free from extreme temperature conditions and dust.

Compatibility

Compatible with all Bluetooth-enable mobile phone.

Specification

Bluetooth Version: V4.0+EDR

Frequency: 2400.0-2483.5MHz

Bluetooth Supported: Headset, Handsfree, A2DP and AVRCP

Chipset: CSI

Operation Range: 10m

Talking Time: > 10 Hours
Charging Time: about 3 hours
Music Playing Time: > 8 hours
Stand-by Time: > 300 hours

Weight: 200 g

Guarantee

Oricore has high level requirement for the quality. All products are developed and produced understrict environment and tested by standard method. So please follow the instruction to operate the product, we will try our best to help you when product problem happen, supply the best and convenient service in the guarantee period. Even after the guarantee period, we also supply service and only charge the cost of material. Please fill the data carefully to ensure the after-sale service.

Product Information Card

Please read the user guide carefully and keep it properly for future review.



www.oricore.com