

BLUETOOTH HEADSET

► User Guide ◀

www.oricore.com

appearance, simple button function and fashionable design, it is your best choice. Attention: The headset connected with your Bluetooth equipment. The headset comes with a built-in rechargeable battery. Prior to using the headset for the first time, it is recommended to fully charge the battery. 1. LB-350S Bluetooth **Headset Overview** 1. Power Button 5. Speaker

Thank you for selecting ultra-thin Bluetooth headset LB-350S.sleek

2 Charging Socket 3. Volume + 4. Volume -

8, Answer/Reject Button



6, LED Indicator 7, Microphone

Charging Your Headset The LED will be red when charging, then the battery is fully charged, the red LED will turn off

3. Turning Your Headset On and Off
Press and hold the Power Button for 3 seconds to turn your headset on and

off. 4. Pairing Your Headset

Pairing your headset first time:

2 hours are required to fully charge the headset.

1.Place the headset and the mobile phone no more than one meter apart.
 2. Ensure the headset is turned off.

• 02 •

3.Press the Power Button for 5 seconds until the LED alternately flashes red and blue.

4.Set the mobile phone to search for Bluetooth devices within range, and

select "LB-350S" from the list of devices shown.

5.Enter the passkey "0000" and press "OK" to pair your headset with the mobile phone.

**If your phone is 2.1, it is no pood to enter the

the mobile phone.
*If your phone's Bluetooth version is 2.1, it is no need to enter the passkey when pairing. For some mobile phone, Pairing is completed, you still

need to connect mobile phone to Bluetooth headset by manual control.

5. Using Your Headset Answering a Call

When a call is coming, press the Answer/Reject Button to accept the call or answer the call via your mobile phone in the normal way. Ending a Call

While speaking, press the Answer/Reject Button once to end the call. Rejecting a Call

When a call is coming, press the Answer/Reject Button, to reject the incoming call

Voice Dialling from Your Headset If your mobile phone is equipped with voice dialling function, in standby status, press the Answer/Reject Button to use the voice dialling.

· 04 ·

Last Number Redialling from Your Headset In standby status, double press the Answer/Reject Button to redialling the last number

Adjusting the Volume

While speaking, adjust the volume key repeatedly until you reach the desirable volume level. Note: Adjust volume appropriately, too high volume does harm for your

ear.

hearing. Wearing Your Headset You can choose whether to use ear hook, reversible ear hook, wear on either

Product Specifications Bluetooth Version: V3 0+FDR Class II Bluetooth Profiles Supported: Headset, Handsfree

Range Of Frequency: 2400.0-2483.5MHz operation range: 10m Talk Time:

Up to 5 hours Standby Time: Up to 100 hours 2-3 hours

Charging Time: Dimensions: 52x16x9mm Weight: 8 grams